


Size Guide

KRUUSE Rehab Lifting Harness for Hind Legs

- A Measure the circumference of the abdomen directly in front of the back legs.
- B Measure the circumference of the upper thigh (back leg) at the point where it meets the body.

		Lifting Harnes for Hind Legs	
Cat. No	Size	A	В
		Abdomen	Upper thigh
161585	XS	30-36 cm	28-32 cm
161586	S	36-43 cm	33-37 cm
161587	М	43-51 cm	38-42 cm
161588	L	51-61 cm	48-52 cm
161589	XL	61-73 cm	54-58 cm




KRUUSE Rehab Lifting Harness for Front Legs

- C Measure the circumference of the chest directly behind the front legs.
- D Measure the circumference of the front leg at the point where it meets the body.

		Lifting Harnes for Front Legs	
Cat. No	Size	С	D
		Chest	Front leg
161577	XS	40-46 cm	24-26 cm
161578	S	44-52 cm	28-32 cm
161579	М	52-62 cm	34-38 cm
161581	L	62-74 cm	44-48 cm
161582	XL	74-86 cm	54-58 cm





www.kruuse.com Page 37